

MASS AIRFLOW SENSOR CLEANER



Description	Contents	Art. No.	Pack Qty.
Mass Airflow Sensor Cleaner	400ml	0893 560 400	1/24

Recommendation:

Use mass airflow sensor cleaner each time the air filter is replaced.

Specifically developed to safely clean the mass airflow sensors. Periodic use of mass airflow sensor cleaner will keep the engine running at peak efficiency. Increase horsepower and improve air/fuel ratio.

Features:

- Improves drivability.
- Restores loss of performance.
- Maintains proper air / fuel ratio.
- Sensor and plastic safe.
- Quick drying.

Application:

Turn the engine off. Remove the sensor from the air duct. Spray the mass airflow sensor cleaner for about 5-7 seconds to clean it. Let the sensor dry completely. Reinstall it and start the engine.

Note:

Do not use any brushes or tools to clean the sensor. The sensor has to be completely dry before it can be reinstalled in the car.

Air-Con

Exhaust

Cooling

Steering

Trans

Intake

Fuel

Oil